

Indoor Camera System Precautions



Do not plug the Power Supply into a power outlet where it will be exposed to high temperatures.



Use the enclosed strain-relief suction cup on the camera cable when attaching your camera to a window.



Do not plug the Power Supply or USB Receiver into a surge protector or UPS.



Press suction cup firmly against clean glass when mounting camera to an indoor window.



The Indoor Camera is intended for indoor use only.

Tips & Tricks



Focus your indoor Camera the easy way: Plug it into an outlet near your PC and adjust the focus by manually rotating the lens.

Make sure you clean both sides of any window you plan on using with your Indoor Camera window mount.



Adjust motion-recording sensitivity and zones using Setup Recording Options in the Wilife Software. See the User Guide for details.

Ensure a solid hold for your window mount by applying a small drop of vegetable or olive oil to the inside outer edge of the suction cup.



Find additional accessories that can enhance your Wilife Video Security System at www.wilife.com.

Easily enable or disable the red light on the front of your camera using the Camera tab on the Setup screen of Command Center.



A Logitech Company